



Installation Guide

Wall & Ceiling Mounted Showers


Suits Models:

30573, 34192, 30016, 30017, 30018, 30575, 30665, 30666, 30667, 30668, 35108, 35109, 35138


Important requirements:



Must be fitted in accordance with AS/NZS 3500 by qualified plumber



Mains 500kpa regulator must be fitted



Maximum hot water temp. 65°C



Only clean municipal water supply. No bore, dam or hard water without filtration & treatment

Cleaning

Clean only with a soft microfiber or similar cloth and warm clean water. Ensure that the cloth is clean and free of any grit or chemical. Dry tap off with a soft clean cloth. Ensure that your tap is not subject to any chemicals, building grit or any type of abrasive or polish. For care of special finishes please visit our website.

Maintenance

Aerators may need to be flushed from time to time if flow diminishes or stream pattern deteriorates. For Pegasi & Cascade mixers, use the aerator key provided to unscrew the aerator. You will notice a "castle" pattern around the edge of the aerator, the key engages with this allowing you to unscrew the insert easily. For Zeos models, use the aerator key to unscrew the aerator housing, you will then be able to pop the insert out the top of the housing. Rinse off the upper face of the insert with running water and gently brush clean with an old toothbrush to remove any debris before refitting the aerator.

Installation

1. Ensure that the ½" water supply lug is not protruding from the wall more than 15mm. Remove any debris or tile glue from the lug, wind sufficient thread tape onto the lug.
2. Place the flange on the shower arm (For Cascade place the dress ring behind the already fitted flange).
3. Screw the arm onto the lug by hand (do not use wrench) until the arm is close to the tiles
4. Press the flange up against the wall on Pegasi and Zeos models.
5. Fit the shower head to the arm (no thread tape required) and fasten gently using a shifting spanner.
6. Run and test the shower.
7. The lower nut on the ball joint may be tightened slightly by hand should the swivel action be too loose.

